



Standard - SV008 Cajun Heat

Content	Vinyl Surface with Polyester / Cotton Backing
Finish	Advanced Soil and Stain Resistant Top Coat
Cleaning Code	<b>(W-S)</b> For water-based stains use water-based cleaners. For oil-based stains use solvent-based cleaners. We recommend using a professional cleaning service.  Bleach solutions of up to 10% may be used for more difficult stains.

Visit [www.statmedicalcanada.com/standard-vinyls](http://www.statmedicalcanada.com/standard-vinyls) for complete specifications.

## Maintenance / General Recommendations

Clean and maintain your furniture regularly. Cleaning frequency depends on use. We recommend using a professional furniture cleaning service.

Always test cleaning solutions and methods in an inconspicuous area of the furniture before proceeding. Treat spills and stains promptly. The longer the stain remains, the more difficult it will be to remove. Clean spots or stains from the edge of the stain working toward the center.

For regular cleaning and maintenance, remove excess soil with a damp, non-abrasive cloth. Use a solution of mild liquid soap and water. Rinse with clean water and dry.

## Stain Treatment / Disinfection

For more difficult stains or to disinfect, use a mixture of no more than 10% bleach and 90% water. **Always** rinse with clean water and dry. **Never** use full strength bleach to clean this material or any other coated fabric.

If stain persists, allow the diluted bleach solution to puddle on the affected area or apply with a clean, soaked cloth for approximately 30 minutes. Rinse with water-dampened cloth to remove any remaining bleach residue.

We do not recommend the use of hard surface cleaners; however, the following cleaners / disinfectants have been tested for use on this material, diluted per manufacturer's instructions:

CaviWipes™
Virex® II 256
Virox® 5

Marks are the property of their respective owners. No affiliation or endorsement is implied.

If these cleaners / disinfectants are used, the material **must** be rinsed with clean water and dried with a clean cloth following application. Failure to rinse thoroughly with clean water and to pat dry may lead to cleaner build up and cause surface deterioration (cracking, blisters, peeling, discoloration, etc.).

Do **not** use cleaners marked "for hard non-porous surfaces only" unless indicated above. Such use may cause surface deterioration (cracking, blisters, peeling, discoloration, etc.).

### Caution:

- Indiscriminate use of strong cleaning chemicals can severely damage or discolor this material.
- Never apply full strength bleach to this material.
- Avoid cleaners containing abrasives.
- Do not use heat to clean this material. Hot water, hot water extraction, or steam cleaning is not recommended.
- Do not saturate material or let cleaning agents pool in seams.
- Several light applications of a cleaning agent are less harmful than a single concentrated application.
- Certain apparel dyes, including indigo dyes commonly used in denim jeans, may migrate on to the surface of the material and become visible on lighter colors. This phenomenon is increased by humidity and temperature and may be irreversible.
- Certain inks, including ball point ink can create permanent stains.
- If stain persists despite suggested cleaning methods, stain has probably set and may be permanent.
- Some solvents are highly flammable. Exercise proper care when cleaning with solvents and solvent cleaners. Read and follow manufacturer's directions on labels.

The information published in this Care Guide refers to performance of this product in specific tests conducted under laboratory conditions. Results may vary under actual conditions.

The information published in this Care Guide is not a guarantee and does not relieve the user from the responsibility of proper and safe use of the product and all cleaning agents. The use of certain agents can be harmful to the surface appearance and lifespan of the material. Stat Medical Inc. assume no responsibility resulting from the use of such cleaning agents on the material.

Under no circumstances shall Stat Medical Inc. be liable for any incidental, consequential, or other damage resulting from the negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance and cleaning. Information relating to chemicals/cleaning agents, environmental use and human exposure should be reviewed with the appropriate suppliers. All label instructions on their use and precautions should be followed.

